


**LPV11 printer system
user's manual**

digital pdp11/03



**LPV11 printer system
user's manual**

EK-LPV11-OP-001

Copyright © 1977 by Digital Equipment Corporation

The material in this manual is for informational purposes and is subject to change without notice.

Digital Equipment Corporation assumes no responsibility for any errors which may appear in this manual.

Printed in U.S.A.

This document was set on DIGITAL's DECset-8000 computerized typesetting system.

The following are trademarks of Digital Equipment Corporation, Maynard, Massachusetts:

DEC	DEctape	PDP
DECCOMM	DECUS	RSTS
DECsystem-10	DIGITAL	TYPESET-8
DECSYSTEM-20	MASSBUS	TYPESET-11
		UNIBUS

CONTENTS

	Page
CHAPTER 1 INTRODUCTION	
1.1 GENERAL.....	1-1
1.2 OPTIONS.....	1-1
1.2.1 General	1-1
1.2.2 LP05 Line Printers.....	1-4
1.2.3 LA180 DECprinter.....	1-4
1.3 SPECIFICATIONS	1-4
1.3.1 LPV11 Interface Module (M8027)	1-4
1.3.2 Interface Cable	1-6
1.3.3 LP05 Line Printer	1-6
1.3.4 LA180 DECprinter.....	1-7
1.4 RELATED HARDWARE MANUALS.....	1-8
CHAPTER 2 INSTALLATION	
2.1 GENERAL.....	2-1
2.2 CONFIGURING INTERFACE MODULE JUMPERS.....	2-1
2.2.1 General	2-1
2.2.2 Device Address.....	2-3
2.2.3 Interrupt Vector Address.....	2-3
2.2.4 Optional Features.....	2-4
2.3 LPV11 INTERFACE MODULE INSTALLATION	2-4
2.3.1 Device Priority	2-4
2.3.2 Module Installation.....	2-6
2.4 PRINTER INSTALLATION.....	2-7
2.4.1 LA180 Installation	2-7
2.4.2 LP05 Installation.....	2-7
2.5 PRINTER SYSTEM CHECKOUT.....	2-7
CHAPTER 3 PROGRAMMING	
3.1 PROGRAMMING SPECIFICATIONS	3-1
3.1.1 Printer Commands	3-1
3.1.2 LPV11 Device Registers	3-2
3.1.3 Interrupts	3-4
3.1.4 Printer Operation	3-5
3.2 PROGRAMMING EXAMPLE.....	3-5
CHAPTER 4 TECHNICAL DESCRIPTION	
4.1 GENERAL.....	4-1
4.2 LPV11 INTERFACE FUNCTIONS	4-1
4.2.1 General	4-1

CONTENTS (Cont)

		Page
4.2.2	Bus Transceivers and Drivers.....	4-1
4.2.3	Device Address Decoding.....	4-1
4.2.4	Print Data Transmission.....	4-1
4.2.5	Read Data Select Logic.....	4-2
4.2.6	Ready Flag and LP Strobe Logic.....	4-2
4.2.7	Error Filter.....	4-2
4.2.8	BRPLY Delay.....	4-2
4.2.9	Initialization.....	4-2

CHAPTER 5 MAINTENANCE

5.1	GENERAL.....	5-1
5.2	DIAGNOSTIC SOFTWARE.....	5-1
5.3	DIGITAL SERVICES.....	5-1

FIGURES

Figure No.	Title	Page
1-1	LP05 Line Printer.....	1-2
1-2	LA180 DECprinter.....	1-3
2-1	LPV11 Interface Module.....	2-2
2-2	LPV11 Device Address Format and Jumpers.....	2-3
2-3	LPV11 Interrupt Vector Address Format and Jumpers.....	2-3
2-4	Typical H9270 Backplane Processor and Option Locations.....	2-5
2-5	Typical DDV11-B Backplane.....	2-6
2-6	Module Installation.....	2-6
3-1	LPV11 Word Formats.....	3-4
4-1	LPV11 Interface Logic Functions.....	4-3
4-2	LP05 Strobe Timing.....	4-5
4-3	LA180 Strobe Timing.....	4-6

TABLES

Table No.	Title	Page
1-1	LPV11 Option Summary	1-1
1-2	LPV11 Backplane Pin Utilization	1-5
2-1	LP05 Interface Cable (70-11212) Pin Assignments	2-7
3-1	LPV11 Command Character Summary	3-1
3-2	LPCS Register Bit Functions	3-2
3-3	LPDB Register Bit Functions	3-4
4-1	Uppercase-Only Code Translation	4-7

TABLE

Page No.	Title	Page No.
10	1. General Summary of the Project	10
11	2. Objectives and Scope of the Study	11
12	3. Methodology and Data Collection	12
13	4. Results and Discussion	13
14	5. Conclusions and Recommendations	14
15	6. References	15
16	7. Appendix A: Raw Data	16
17	8. Appendix B: Statistical Analysis	17

CHAPTER 1 INTRODUCTION

1.1 GENERAL

The LPV11 is a high speed/line printer system option for the LSI-11 family of microcomputers. Twelve LPV11 models define the type of printer supplied and primary power (line) voltage. Printer types include the LA180 DECprinter, and two LP05 line printer models (uppercase letters only, and both upper- and lowercase letters). Each LP05 printer system includes an LSI-11 bus-compatible interface module (M8027) that plugs into any LSI-11 bus-structured backplane, a printer, and an interface cable. Printers are shown in Figures 1-1 (LP05 line printer) and 1-2 (LA180 DECprinter).

This manual includes information for installing and programming the LPV11. Detailed information is provided for the LPV11 interface only; refer to the appropriate printer manual (LA180 or LP05) supplied with the LPV11 option for detailed information on the printer.

1.2 OPTIONS


1.2.1 General

LPV11 printer systems are available in twelve models. A list of LPV11 models is provided in Table 1-1.

Table 1-1 LPV11 Option Summary


Option No. (Model)	Interface Cable*	Primary Power	Model	Printer Description
LPV11-PA	BC11S-25	115 V, 60 Hz	LA180-PA	180 char/s printer, 132 column, upper- and lowercase letters
LPV11-PB	BC11S-25	230 V, 60 Hz	LA180-PB	
LPV11-PC	BC11S-25	115 V, 50 Hz	LA180-PC	
LPV11-PD	BC11S-25	230 V, 50 Hz	LA180-PD	
LPV11-VA	70-11212-25	115 V, 60 Hz	LP05-VA	300 line/min printer, 132 column, uppercase letters
LPV11-VB	70-11212-25	230 V, 60 Hz	LP05-VB	
LPV11-VC	70-11212-25	115 V, 50 Hz	LP05-VC	
LPV11-VD	70-11212-25	230 V, 50 Hz	LP05-VD	
LPV11-WA	70-11212-25	115 V, 60 Hz	LP05-WA	240 line/min printer, 132 column upper- and lower case letters
LPV11-WB	70-11212-25	230 V, 60 Hz	LP05-WB	
LPV11-WC	70-11212-25	115 V, 50 Hz	LP05-WC	
LPV11-WD	70-11212-25	230 V, 50 Hz	LP05-WD	

*7.62 m (25 ft) interface cable is supplied with each option.



6996-2

Figure 1-1 LP05 Line Printer



7595-5

Figure 1-2 LA180 DECprinter

1.2.2 LP05 Line Printers

LP05 printers (Figure 1-1) use a 132-column, 64- (LPV11-VA, -VB, -VC, -VD) or 96- (LPV11-WA, -WB, -WC, -WD) character rotating drum, and solenoid driven hammers to print characters. Characters are transmitted to the LP05's print buffer under program control via the M8027 interface module. The LP05 print buffer stores up to a 132-character line. Each print cycle is initiated by a terminating character. Terminating characters include carriage return (CR), line feed (LF), and form feed (FF). Printing requires two revolutions of the drum. Odd-numbered and even-numbered columns are printed during alternate revolutions of the drum. Circuits in the LP05 scan the print buffer characters stored for a line in synchronization with the rotating drum. Each character is printed, as appropriate, by driving the hammer for those odd- or even-numbered columns in which a particular character appears. An inked ribbon and paper pass between the drum and the hammers, and thus the characters are printed.

Note that LP05 printers are available with uppercase letters only (64 character set) or upper- and lowercase letters (96 character set) depending upon model. All models are capable of printing numerals and punctuation marks.

1.2.3 LA180 DECprinter

The LA180 DECprinter included with LPV11-PA, -PB, -PC, and -PD models is a free-standing, pedestal-type impact printer that is capable of printing a maximum of 132 characters per line. To initiate a print cycle, a line terminator character (LF, FF, or CR) is required. The printer contains a 256 by 8 character buffer which stores printable and non-printable characters. This buffer is loaded character-by-character via the LPV11 interface under program control. After each character is stored in the buffer, a read function is performed to determine if the character is a line terminator character. If it is, the characters stored in the buffer are printed; if it is not, the next characters are input until the complete line is stored, as indicated when the line terminator character is received and stored.

Each character is transferred to the printer as a parallel 7-bit ASCII plus optional parity code. The printer is a high-speed dot matrix printer that prints at speeds up to 180 characters per second. It produces a hard copy original plus up to five duplicate copies on tractor-driven continuous forms, varying in width from 10.2 cm (4 in) to 37.8 cm (14-7/8 in). The average printing speeds are 70 lines per minute on full lines, and 300 lines per minute on short lines. The printer responds only to codes representing the LA180 character set and six command characters. All other codes are ignored. Refer to the LA180 DECprinter manual supplied with the LPV11 option for detailed printer information.

1.3 SPECIFICATIONS

1.3.1 LPV11 Interface Module (M8027)

The LPV11 interface module can be installed in any LSI-11 bus structured backplane. Standard device and interrupt vector addresses are factory configured. Non-standard addresses can be configured by the user by removing and/or installing jumpers on the module. A 40-pin connector (J1) allows the user to connect the module to the printer via an appropriate cable supplied with the LPV11 option (defined in Table 1-1).

Size

Height	13.2 cm (5.2 in)
Length	22.8 cm (8.9 in)
Width	1.27 cm (0.5 in)

Environmental Operating Temperature

5 to 50° C (40 to 122° F) with a relative humidity of 10% to 95% (no condensation), and adequate airflow across the module. When operating at the maximum temperature (50° C or 122° F), airflow must maintain the inlet-to-outlet air temperature rise across the module to 7° C (12.5° F) maximum.

Storage Temperature Range

-40 to 66° C (-40 to 150° F)

Bus Backplane Pinning

Refer to Table 1-2.

Power Requirements

+5 V ± 5%, 0.8 A (1.4 A maximum)

Table 1-2 LPV11 Backplane Pin Utilization

Module Side 1 (Component Side)		Module Side 2 (Solder Side)	
Backplane Pin	Signal Mnemonic	Backplane Pin	Signal Mnemonic
AA1		AA2	+5 V
AB1		AB2	
AC1		AC2	GND
AD1		AD2	+12 V
AE1		AE2	BDOUT L
AF1		AF2	BRPLY L
AH1		AH2	BDIN L
AJ1	GND	AJ2	BSYNC L
AK1	CLK OUT	AK2	BWTBT L
AL1	CLK IN	AL2	BIRQ L
AM1	GND	AM2	BIAKI L
AN1		AN2	BIAKO L
AP1		AP2	BBS7 L
AR1		AR2	BCMGI L
AS1		AS2	BDMGO L
AT1	GND	AT2	BINIT L
AU1		AU2	BDAL0 L
AV1		AV2	BDAL1 L
BA1		BA2	+5 V
BB1		BB2	
BC1		BC2	GND
BD1		BD2	
BE1		BE2	BDAL2 L
BF1		BF2	BDAL3 L
BH1		BH2	BDAL4 L
BJ1	GND	BJ2	BDAL5 L
BK1		BK2	BDAL6 L
BL1		BL2	BDAL7 L
BM1	GND	BM2	BDAL8 L
BN1		BN2	BDAL9 L
BP1		BP2	BDAL10 L
BR1		BR2	BDAL11 L
BS1		BS2	BDAL12 L
BT1	GND	BT2	
BU1		BU2	
BV1	+5 V	BV2	BDAL15 L

NOTE

AK1 and AL1 are connected together by the LSI-11 backplane when the module is plugged into the backplane.

1.3.2 Interface Cable

Type BC11S-25 or 70-11212-25, depending on LPV11 model (Table 1-1)

Length 7.62 m (25 ft) maximum

1.3.3 LP05 Line Printer

Power 115 Vac \pm 10%, 50/60 Hz \pm 3 Hz or
230 Vac \pm 10%, 50/60 Hz \pm 3 Hz
700 W

Printable Characters !"#\$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_

96-character set All of the above plus a through z : ~

Type Open Gothic print

Size Typically 0.024 cm (0.095 in) high; 0.065 cm (0.065 in) wide

Code Format ASCII

Characters Per Line 132

Character Drum Speed 64-Character Drum 1200 r/min
96-Character Drum 800 r/min

Printer Characteristics

Format Top-of-form control; single line advance with automatic perforation step-over, and carriage return. Automatic vertical format control is optional.

Paper-Feed One pair of pin-feed tractors for 1.27 cm (1/2 in) hole center, edge-punched paper.

Paper Slew Speed 50.8 cm (20 in) per second

Print Area 33.53 cm (13.2 in) wide, left justified

Character Spacing (horizontal) 0.254 \pm 0.0127 cm (0.1 \pm 0.005 in) between centers; maximum possible accumulative error for normal spacing is 0.0254 cm (0.01 in) per 80- or 132-character line.

Line Spacing 0.424 \pm 0.025 cm (0.167 \pm 0.01 in) at 6 lines per inch; 0.3175 cm (0.125 in) at 8 lines per inch. Each character within \pm 0.254 cm (0.1 in) from mean line through character.

Line Advance Time 50 ms maximum

Character Synchronization Variable reluctance pick-off senses drum position.

Physical Characteristics

Height 1.14 m (45 in)
Width 0.81 m (32 in)
Depth 0.56 m (22 in)
Weight 150 kg (330 lb)

Ribbon Characteristics

Type Inked roll
Width 38.1 cm (15 in)
Length 18.288 m (20 yd)
Thickness 0.01 cm (0.004 in)

Paper Characteristics

Type Standard fanfold, edge punched, 27.94 cm (11 inches) between folds.
Width 10.16 cm to 42.55 cm (4 in to 16-3/4 in) 15 lb bond minimum (single copy) 12 lb bond with single-sheet carbon for up to six parts (multiple copy)
Weight 15 lb bond minimum (single copy)
12 lb bond with single-sheet carbon for up to six parts (multiple copy)

Environmental

Operating Temperature 10 to 32° C (50 to 90° F).
Humidity 30% to 90% (no condensation)

Print Rates

LP05-VA, -VB, -VC, -VD 300 line/min
(64-character drum)
LP05-WA, -WB, -WC, -WD 240 lines/min
(96-character drum)

1.3.4 LA180 DECprinter

Power 90-132 Vac or 180-264 Vac
50 or 60 Hz ± 1 Hz
400 W max (printing)
200 W max (idle)

Printable Characters

96 upper- and lowercase character set (7 × 7 dot matrix):

+ , - . / 0 1 2 3 4 5 6 7 8 9 : ; < = > ? @ A B C D E F G H I J K L M N O P Q R S T
U V W X Y Z [\] ^ _ ` a b c d e f g h i j k l m n o p q r s t u v w x y z { | } ~
! " # \$ % & ' () *

Code Format ASCII

Non-Printable Characters Six commands: BEL, BS, LF, FF, CR, DEL

Number of Characters Per Line 132 max
 Type of Character Transfer Parallel (7-bit plus parity)

Printer Characteristics

Print Cycle Speed Up to 180 characters per second
 Line Printing Speeds 70 lines per minute on full line
 300 lines per minute on short lines
 Print Size 0.254 cm (10 characters per inch) horizontal
 0.233 cm (6 lines per inch) vertical

1.4 RELATED HARDWARE MANUALS

Title	Document No.
1977-78 Microcomputer Handbook*	EB 07948 53/77
PDP-11V03 System Manual*	EK-11V03-TM-002
PDP-11T03 System Manual*	EK-11T03-OP-001
LA180 DECprinter I User's Manual* (for LPV11-PA, -PB, -PC, or -PD Users)	EK-LA180-OP-002

Dataproducts Corporation

Technical Manual, Model 2230 Line Printer, Volume 1 and Volume 2 (for LPV11-VA, -VB, -VC, -VD, -WA, -WB -WC, or -WD users).

*These documents can be ordered from:
DIGITAL EQUIPMENT CORPORATION
 444 Whitney Street
 Northboro, MA 01532

ATTENTION: **COMMUNICATIONS SERVICES (NR2/M15)**
CUSTOMER SERVICES SECTION

CHAPTER 2 INSTALLATION

2.1 GENERAL

The LPV11 printer option can be installed in any system in the LSI-11 family, including LSI-11 component systems, PDP-11/03, PDP-11V03, and PDP-11T03 systems.

Installation involves:

1. Installing the LPV11 interface module in the LSI-11 backplane
2. Installing the printer (connecting ac power and connecting to the LSI-11 system via an interface cable).

Each interface module is shipped from the factory with jumpers configured for standard (DEC software-compatible) device and interrupt vector assignments. It is normally not necessary for the user to configure address or vector jumpers unless special device and/or interrupt vectors are desired. They can be configured as directed in Paragraph 2.2. The factory (or user) configured module can be installed as directed in Paragraph 2.3.

CAUTION

Modules must be installed or removed only when dc power is removed from the backplane.

The remainder of this chapter contains specific instructions for configuring and installing the LPV11 interface module (check jumper configuration before installing module), and installing the printer (LP05 or LA180). Use only those procedures applicable to the specific option model (type of printer).


2.2 CONFIGURING INTERFACE MODULE JUMPERS

2.2.1 General

LPV11 interface module jumpers are located as shown in Figure 2-1. Factory-installed jumpers can be removed by carefully cutting each end close to the printed circuit board. Note that factory-installed jumpers have W numbers assigned. Adjacent to each factory-installed jumper location are wire-wrap pins allowing a user to reinstall a jumper previously removed. The remaining jumpers (not factory installed) can be installed using the designated wire-wrap pins. Dots in Figure 2-1 represent wire-wrap pins; a line connecting a pair of pins shows the electrical connection that must be wire-wrapped to insert that jumper.

Note

Jumper F+ (factory installed W6) and F- do not have associated wire-wrap pins. These jumpers must be installed by soldering and removed by cutting or unsoldering.



NOTE

○ — JUMPERS BROKEN FOR CLARITY ON THIS FIGURE. THESE WIRE-WRAP JUMPERS WOULD NORMALLY BE USED TO REPLACE PREVIOUSLY REMOVED FACTORY-INSTALLED ("W") JUMPERS (SHOWN INSTALLED).

○ = WIRE WRAP PIN

Figure 2-1 LPV11 Interface Module

11-5521

2.2.2 Device Address

The LPV11 is factory-configured for device control/status register (CSR) address equal to 177514. The data buffer register (DBR) is always the configured CSR address +2; thus, the standard DBR address is 177516. If more than one LPV11 option is installed in the system, or if special device addresses are desired, remove and/or install jumpers (one for each CSR address bit) as directed in Figure 2-2.




Figure 2-2 LPV11 Device Address Format and Jumpers

2.2.3 Interrupt Vector Address

The LPV11 is factory-configured for an interrupt vector address equal to 200. If more than one LPV11 option is installed in the system, or if a special interrupt vector address is desired, remove and/or install jumpers (one for each vector address bit) as directed in Figure 2-3.




Figure 2-3 LPV11 Interrupt Vector Address Format and Jumpers

2.2.4 Optional Features

Optional jumpers alter LPV11 operation for specific functional purposes. These functions, and their associated jumpers are described as follows.

Bus Reply Timing – Jumper D (W1) is factory-installed to delay the BRPLY L bus signal timing for LPV11 use with LA180 printers. If desired, this jumper can be removed for use with future printers; however, the LP05 will function if it is left installed.

Uppercase Only – Jumper W7 is factory installed and jumper T is not installed, enabling upper- and lowercase letters to be printed. If lowercase letters are not desired, remove W7 and install jumper T. This will cause the LPV11 interface to translate all lowercase letters to uppercase letters before transmission to the printer. This feature will allow printing files configured for 96-character printers on 64-character printers with minimum software overhead.

Do not configure the module with both jumpers W7 and T installed.

Parity – Jumpers W8 and P select the desired parity mode. The LPV11 is factory-configured with W8 installed and jumper P not installed, enabling parity bit 07 to be transmitted to the printer. Configure the parity option desired as follows.

Parity Option	Jumper W8	Jumper P
Normal parity bit	Installed	Removed
No parity, bit 07 low	Removed	Removed
No parity, bit 07 high	Removed	Installed

Do not configure the module with both jumpers W8 and P installed.

NOTE

If the LPV11 interface module is used with an LP05 printer equipped with the Direct Access Vertical Form Unit (DAVFU), it is recommended that the user remove jumper W8. The LP05 interface module does not support the DAVFU function.

Error Filter – The LPV11 interface module contains an error filter (time delay) circuit that is automatically selected when the module is used with an LA180 DECprinter. Jumper F+ (W6) is factory installed selecting the error filter for use with LP05 printers; however, its use with the LP05 is optional. If desired, remove the error filter by removing jumper W6 and installing jumper F-. Do not configure the module with both F- and W6 installed.

2.3 LPV11 INTERFACE MODULE INSTALLATION

2.3.1 Device Priority

LPV11 device priority must be first considered to determine which backplane slot in which the LPV11 module will be installed. In all LSI-11 systems, device priority is established by the relative electrical position of device interface modules along the I/O bus. H9270 and DRV11-B backplanes are structured to allow the user to configure device priority by installing modules in appropriate positions. The PDP-11/03 includes one factory-installed H9270 backplane.

Figure 2-4 is a front view of the H9270 backplane, showing typical module locations. The processor module should be installed in backplane slots A1-D1.




Figure 2-4 Typical H9270 Backplane Processor and Option Locations

The LSI-11 bus structure includes two daisy-chained signals: BIAKO L/BIAKI L (for interrupts) and BDMGO L/BDMGI L (for DMA grant). These signals normally propagate through option modules until they reach the requesting device. Option 1, as shown in Figure 2-4, is the first device location to receive the daisy-chained signals when the processor module is installed in slots A1-D1. Hence, six options can be installed in the backplane. The PDP-11/03 is shipped with the processor module installed in the backplane as shown in the figure. Do not relocate the processor module to another location; a separate non-based (jumper) connection is provided on the backplane to this location for proper RUN indicator operation.

CAUTION

Do not configure the system with unused option locations in the backplane between the processor module and I/O devices that require either of the two daisy-chained signals; an unused location will break the daisy-chain signal continuity, and devices in higher numbered locations will not receive interrupt or DMA grant signals. Unused locations should occur only in the highest numbered option locations.


Note that the daisy-chained BIAK and BDMG signals always follow in increasing numbered option locations, as shown in the figure.

Device priority on the DDV11-B backplane is established in the same manner as described for the H9270 backplane. However, larger physical size allows up to 16 options (including a bus terminator module) to be installed on the backplane. Device (option) locations are shown in Figure 2-5. This highest priority location is option 1; the lowest priority location is option 16.

Since the LPV11 printer system only functions as an output device, and if it is interrupted by higher priority devices there is no danger of losing data, it can be located on the backplane as a low priority device. Install input devices as the higher priority devices.

Refer to the Microcomputer Handbook for system installation and bus termination details when the system contains MMV11-A core memory or more than six memory or peripheral device options.

VIEW FROM MODULE SIDE OF BACKPLANE



MR - 0338

Figure 2-5 Typical DDV11-B Backplane

2.3.2 Module Installation


Modules must be installed or removed only when dc power is removed from the backplane. The PDP-11/03 contains a control/indicator panel on the front of the power supply; the DC ON/OFF switch allows the user to turn off dc power for safe module insertion and removal.

Modules must be installed in the backplane with components facing row 1, as shown in Figure 2-6.

CAUTION

The LSI-11 modules and the backplane assembly mounting blocks may be damaged if the modules are plugged in backward.

DC power must be removed from the backplane during module insertion or removal.



CP1761

Figure 2-6 Module Installation

2.4 PRINTER INSTALLATION

Connect the LA180 or LP05 printer to the LPV11 interface module as directed in the following paragraphs. Connector J1 is located on the LPV11 interface module as shown in Figure 2-1.

CAUTION

Turn off LSI-11 system power and the printer power whenever installing or removing the printer's interface cable or interface module.

2.4.1 LA180 Installation

LPV11 printer systems equipped with the LA180 printer include the *LA180 DECprinter I User's Manual*. Refer to this manual for detailed installation procedures for the LA180 printer.

Connect the printer to the LPV11 interface module using the BC11S-25 cable supplied with the option. (Cable pinning is described in the printer manual.) Connect one end (P2) to the printer (J3) as directed in the printer manual. Connect the free end (P1) to the LP05 interface module connector (J1).

2.4.2 LP05 Installation

LPV11 printer systems equipped with the LP05 printer include the *Dataproducts Corporation Model 2230 Line Printer Technical Manual, Volume 1*. Refer to this manual for detailed installation procedures for the LP05 line printer.

Connect the printer to the LPV11 interface module using the 70-11212-25 cable supplied with the option. (Cable pinning is described in Table 2-1.) Connect one end of the cable (P1) to the interface connector on the rear of the LP05 line printer. Connect the free end (P2) to the LP05 interface connector (J1).

2.5 PRINTER SYSTEM CHECKOUT

After the printer system is installed, the system can be checked for proper operation by executing ZJ178-RB LP11/LP05 diagnostic software included with the LPV11 option. The diagnostic software kit includes a diagnostic program paper tape and documentation. Operating instructions and program listings for the diagnostic program are included in the documentation.

Table 2-1 LP05 Interface Cable (70-11212) Pin Assignments

From P1 (LP05)	To P2 (M8027)	Signal Name
B	JJ	P DATA 1 (LSB) ✓
C	W	P DEMAND RET
D	HH	P DATA 1 RET ✓
E	X	P DEMAND
F	LL	P DATA 2 ✓
J	XX	P DATA 2 RET
L	BB	P DATA 3 ✓
N	AA	P DATA 3 RET
R	FF	P DATA 4 ✓
T	EE	P DATA 4 RET
V	TT	P DATA 5 ✓
X	SS	P DATA 5 RET
Y	U	VERIFY RET
Z	RR	P DATA 6

Table 2-1 LP05 Interface Cable (70-11212) Pin Assignments (Cont)

From P1 (LP05)	To P2 (M8027)	Signal Name
AA BB CC DD EE FF	P V	P FAULT RET CONNECTOR VERIFY
a b c f h j k m n p r s t u w y z	PP VV CC UU DD D C R	P DATA 6 RET P STROBE P DATA 7 RET P STROBE RET P DATA 7 (MSB) P DATA 8 (Parity) P DATA 8 RET SELECT (no connection) P FAULT

Blank = not connected

From P1 (LP05)	To P2 (M8027)	Signal Name
	0	P DATA 8 RET
	1	VERIFY RET
	2	P DATA 7 RET
	3	P DATA 7 (MSB)
	4	P DATA 8 (Parity)
	5	P STROBE RET
	6	P DATA 7 RET
	7	P STROBE
	8	P DATA 6 RET
	9	P FAULT
	10	P FAULT RET
	11	P DATA 7 RET
	12	P DATA 7 (MSB)
	13	P DATA 8 (Parity)
	14	P DATA 8 RET
	15	P DATA 7 RET
	16	P DATA 7 (MSB)
	17	P DATA 8 (Parity)
	18	P DATA 8 RET
	19	P DATA 7 RET
	20	P DATA 7 (MSB)
	21	P DATA 8 (Parity)
	22	P DATA 8 RET
	23	P DATA 7 RET
	24	P DATA 7 (MSB)
	25	P DATA 8 (Parity)
	26	P DATA 8 RET
	27	P DATA 7 RET
	28	P DATA 7 (MSB)
	29	P DATA 8 (Parity)
	30	P DATA 8 RET
	31	P DATA 7 RET

CHAPTER 3 PROGRAMMING

3.1 PROGRAMMING SPECIFICATIONS

3.1.1 Printer Commands

Programs (except diagnostics) written for a specific LPV11 can generally be used for any LPV11 (models including either the LP05 or LA180 printers). Therefore, separate LP05 device handlers are not required for different LPV11 models. However, LP05 and LA180 printers do respond differently to certain non-printing characters (commands). A summary of commands for both printers is provided in Table 3-1. The programmer must use the proper command to produce the desired result with a specific printer. All characters (printing and non-printing) are 7-bit ASCII plus optional parity.

Table 3-1 LPV11 Command Character Summary

Command Character	Code	LP05	Printer's Response to Command LA180
BEL	007	Prints a space	*BEL – Bell Activates alarm bell
BS	010	Prints a space	BS – Backspace Backspace one position
PF or LF	012	PF – Paper Feed Print cycle Carriage return Advances paper one line	LF – Line Feed Print cycle Carriage return Advances paper one line
VT	013	Vertical Tab Prints a space	None
FF	014	Form Feed Print cycle Carriage return Advances paper to the third line of the next form	Form Feed Print cycle Carriage return Advances paper to the first line of next form

*The LA180 produces three different audible alarm signals:

1. Continuous tone – indicates a carriage jam or failure.
2. Repetitive beeping – indicates an out of paper condition or a series of bell codes.
3. Single beep – indicates a bell code.

Table 3-1 LPV11 Command Character Summary (Cont)

Command Character	Code	LP05	Printer's Response to Command LA180
CR	015	Carriage Return Print cycle Carriage return No line feed	Carriage Return Causes all characters in LA180 memory to be printed Carriage return
ELONG	016	Elongated Character Prints a space	None
SEL	021	Select Prints a space	None
DSEL	023	Deselect Prints a space	None
DEL	177	Delete Prints a space	Delete Clears printer buffer of all data

3.1.2 LPV11 Device Registers

All programmed communication with the LPV11 option is via two device registers in the LPV11 interface module. These registers include the Line Printer Control and Status (LPCS) and Line Printer Data Buffer (LPDB). These registers are factory configured with LSI-11 bus addresses 177514 and 177516, respectively, and are software-compatible with DEC software. However, if additional LPV11 options are added to the system, or if the user requires addresses other than those factory configured, it will be necessary to alter interface module jumpers as directed in Paragraph 2.2 and provide an LPV11 program using these special device addresses. Each register is subsequently described in Tables 3-2 and 3-3 and both are shown in Figure 3-1.

Table 3-2 LPCS Register Bit Functions


Bit	Name	Function
15	ERROR	<p>Asserted (1) whenever an error condition exists in the line printer. Error conditions include:</p> <p>LP05 Errors:</p> <ol style="list-style-type: none"> 1. Power off 2. No paper 3. Printer drum gate open 4. Over-temperature alarm 5. PRINT INHIBIT switch off 6. Printer off-line 7. Torn paper

Table 3-2 LPCS Register Bit Functions (Cont)

Bit	Name	Function
		<p>LA180 Errors:</p> <ol style="list-style-type: none"> 1. Fault (paper fault) 2. On-line switch (in off position) <p>Reset by manual correction of error condition if LPCS bit 06 is not set. If bit 06 is set, bit 15 is reset by manual correction of the error and (1) reading the interrupt vector if the interface is "ready," or (2) after reading the LPCS if the interface is "not ready." Read only.</p>
<14:08>	Not used	(Read as 0s)
07	DONE	<p>LP05 – Asserted (1) whenever printer is ready for next character to be loaded. Indicates that previous function is either complete or has been started and continued to a point where the printer can accept the next command. This bit is set by the LSI-11 processor asserting BINIT L; if bit 06 is also set, an interrupt sequence is initiated. Also set by the printer when on-line and ready to accept a character. Cleared by loading (writing into) the LPDB register. Inhibited when bit 15 is set. Read only.</p> <p>LA180 – Asserted (1) when the printer is ready to accept another character. DONE is set by the LSI-11 processor asserting BINIT L and is cleared by loading (output transfer to) the LPDB register. If the INTERRUPT ENABLE bit is set, setting DONE will initiate an interrupt request.</p>
06	INTERRUPT ENABLE	Set or cleared by the program. Also cleared by the LSI-11 processor asserting BINIT L. When set, an interrupt sequence is initiated if either the ERROR or DONE bit is set.
<05:02>	Not Used	(Read as 0s)
01	ON LINE	<p>Not supported and not required by DEC software. The following information is provided for reference only.</p> <p>LA180 – Set when the LA180 is on-line. Read only.</p> <p>LP05 – Not used. (Read as 0.)</p>
00	BUSY	<p>Not supported and not required by DEC software. Information is provided below for reference only.</p> <p>LA180 – Set when the LA180 is printing a line or advancing paper.</p> <p>LP05 – Not used. (Read as 0.)</p>

Table 3-3 LPDB Register Bit Functions

Bit	Name	Function
<15:08>	Not used	(Read as 0s. Data written into these bits is lost.)
07	PARITY or D8	Optional use. (Read as 0.) LA180 - Optional parity bit. LP05 - Optional paper instruction bit. Not supported by the LPV11. (Read as 0.)
<06:00>	DATA	7-bit ASCII character register. Characters are sequentially output to the printer buffer via this register. (Read as 0s.)



11-5524

Figure 3-1 LPV11 Word Formats

3.1.3 Interrupts

Programs written for use with the LPV11 are generally composed of an interrupt-driven routine. When the LPCS register INTERRUPT ENABLE bit is set and either the DONE or ERROR bit is set, an interrupt request is initiated. Entry to the LPV11 service routine is normally via the factory-configured vector addresses 200 (PC) and 202 (PS). When servicing an interrupt and a second interrupt occurs, the second (and subsequent) interrupt may not be recognized. This condition can be avoided by checking for both interrupt conditions (DONE and ERROR) in the interrupt service routine.

3.1.4 Printer Operation

LP05 – Characters are sequentially output to the printer one character at a time, under program control. All characters are output via the LPV11 interface module LPDB register. Characters are stored in the LP05 print buffer until one of three special non-printing characters (CR, PF, or FF) is recognized. When a special character is recognized, the print cycle starts and the complete line is printed.

LA180 – Characters are sequentially output to the printer and stored in the same manner as for the LP05 printer. When a special character [CR, LF (same ASCII code as the LP05 PF character), or FF] is recognized, all characters comprising the line are sequentially printed.

3.2 PROGRAMMING EXAMPLE

A programming example for use with any LPV11 model is as shown. Portions shown include the LPV11 vector locations (200 and 202), one instruction in the main program that enables LPV11 interrupts, and the LPV11 interrupt service routine. Not shown are addresses for the buffer in system memory (BUFADR and BUFEND), the error routine (ERROR) and the printer complete routine, which are user-defined.

```
200:          LPSERV          ;VECTOR TO SERVICE ROUTINE

202:          200             ;SERVICE AT PRIORITY 4
.
.
.

MAIN:        BIS #100,LPCS    ;ENABLE INTERRUPT
.
.
.

LPSERV:      TST LPCS        ;CHECK FOR ERROR
              BMI ERROR      ;BRANCH IF ERROR
              MOV R0,-(SP)    ;SAVE R0
              MOV BUFADR,R0  ;GET BUFFER POINTER

LOAD:        MOVB (R0)+,LPDB  ;LOAD PRINTER BUFFER
              CMP R0,BUFEND  ;END OF DATA?
              BHI PRCOMP     ;YES, GO TO PRINT COMPLETE
              TSTB LPCS      ;NO, CHECK DONE
              BMI LOAD       ;NOT FULL, GET ANOTHER CHAR.

EXIT:        MOV R0,BUFADR    ;SAVE BUFFER POINTER
              MOV (SP)+,R0    ;RESTORE R0
              RTI            ;RETURN TO MAIN PROGRAM

BUFADR:      ;BUFFER DATA POINTER

BUFEND:      ;BUFFER END ADDRESS

ERROR:      ;ERROR ROUTINE START ADDRESS
```

PRCOMP:

LPCS=177514
LPDB=177516

;PRINTER COMPLETE ROUTINE
;START ADDRESS

;LPV11 STATUS REGISTER
;LPV11 DATA BUFFER

Character and register (LPC) are used to control the printer. All characters are output to the printer via the LPV11 status register. Characters are stored in the LPV11 data buffer. The printer is controlled by the LPV11 status register. When a character is received, the printer starts to print. When a character is received, the printer starts to print. When a character is received, the printer starts to print.

A programming example for the printer is shown below. The example shows how to use the LPV11 status register (LPC) and the LPV11 data buffer (LPDB) to control the printer. The example shows how to use the LPV11 status register (LPC) and the LPV11 data buffer (LPDB) to control the printer. The example shows how to use the LPV11 status register (LPC) and the LPV11 data buffer (LPDB) to control the printer.

ADDRESS	OPERATION	COMMENT
0000	START	START ADDRESS
0001	MOV	MOV R0, #0
0002	MOV	MOV R1, #0
0003	MOV	MOV R2, #0
0004	MOV	MOV R3, #0
0005	MOV	MOV R4, #0
0006	MOV	MOV R5, #0
0007	MOV	MOV R6, #0
0008	MOV	MOV R7, #0
0009	MOV	MOV R8, #0
000A	MOV	MOV R9, #0
000B	MOV	MOV R10, #0
000C	MOV	MOV R11, #0
000D	MOV	MOV R12, #0
000E	MOV	MOV R13, #0
000F	MOV	MOV R14, #0
0010	MOV	MOV R15, #0
0011	MOV	MOV R16, #0
0012	MOV	MOV R17, #0
0013	MOV	MOV R18, #0
0014	MOV	MOV R19, #0
0015	MOV	MOV R20, #0
0016	MOV	MOV R21, #0
0017	MOV	MOV R22, #0
0018	MOV	MOV R23, #0
0019	MOV	MOV R24, #0
001A	MOV	MOV R25, #0
001B	MOV	MOV R26, #0
001C	MOV	MOV R27, #0
001D	MOV	MOV R28, #0
001E	MOV	MOV R29, #0
001F	MOV	MOV R30, #0
0020	MOV	MOV R31, #0
0021	MOV	MOV R32, #0
0022	MOV	MOV R33, #0
0023	MOV	MOV R34, #0
0024	MOV	MOV R35, #0
0025	MOV	MOV R36, #0
0026	MOV	MOV R37, #0
0027	MOV	MOV R38, #0
0028	MOV	MOV R39, #0
0029	MOV	MOV R40, #0
002A	MOV	MOV R41, #0
002B	MOV	MOV R42, #0
002C	MOV	MOV R43, #0
002D	MOV	MOV R44, #0
002E	MOV	MOV R45, #0
002F	MOV	MOV R46, #0
0030	MOV	MOV R47, #0
0031	MOV	MOV R48, #0
0032	MOV	MOV R49, #0
0033	MOV	MOV R50, #0
0034	MOV	MOV R51, #0
0035	MOV	MOV R52, #0
0036	MOV	MOV R53, #0
0037	MOV	MOV R54, #0
0038	MOV	MOV R55, #0
0039	MOV	MOV R56, #0
003A	MOV	MOV R57, #0
003B	MOV	MOV R58, #0
003C	MOV	MOV R59, #0
003D	MOV	MOV R60, #0
003E	MOV	MOV R61, #0
003F	MOV	MOV R62, #0
0040	MOV	MOV R63, #0
0041	MOV	MOV R64, #0
0042	MOV	MOV R65, #0
0043	MOV	MOV R66, #0
0044	MOV	MOV R67, #0
0045	MOV	MOV R68, #0
0046	MOV	MOV R69, #0
0047	MOV	MOV R70, #0
0048	MOV	MOV R71, #0
0049	MOV	MOV R72, #0
004A	MOV	MOV R73, #0
004B	MOV	MOV R74, #0
004C	MOV	MOV R75, #0
004D	MOV	MOV R76, #0
004E	MOV	MOV R77, #0
004F	MOV	MOV R78, #0
0050	MOV	MOV R79, #0
0051	MOV	MOV R80, #0
0052	MOV	MOV R81, #0
0053	MOV	MOV R82, #0
0054	MOV	MOV R83, #0
0055	MOV	MOV R84, #0
0056	MOV	MOV R85, #0
0057	MOV	MOV R86, #0
0058	MOV	MOV R87, #0
0059	MOV	MOV R88, #0
005A	MOV	MOV R89, #0
005B	MOV	MOV R90, #0
005C	MOV	MOV R91, #0
005D	MOV	MOV R92, #0
005E	MOV	MOV R93, #0
005F	MOV	MOV R94, #0
0060	MOV	MOV R95, #0
0061	MOV	MOV R96, #0
0062	MOV	MOV R97, #0
0063	MOV	MOV R98, #0
0064	MOV	MOV R99, #0
0065	MOV	MOV R100, #0
0066	MOV	MOV R101, #0
0067	MOV	MOV R102, #0
0068	MOV	MOV R103, #0
0069	MOV	MOV R104, #0
006A	MOV	MOV R105, #0
006B	MOV	MOV R106, #0
006C	MOV	MOV R107, #0
006D	MOV	MOV R108, #0
006E	MOV	MOV R109, #0
006F	MOV	MOV R110, #0
0070	MOV	MOV R111, #0
0071	MOV	MOV R112, #0
0072	MOV	MOV R113, #0
0073	MOV	MOV R114, #0
0074	MOV	MOV R115, #0
0075	MOV	MOV R116, #0
0076	MOV	MOV R117, #0
0077	MOV	MOV R118, #0
0078	MOV	MOV R119, #0
0079	MOV	MOV R120, #0
007A	MOV	MOV R121, #0
007B	MOV	MOV R122, #0
007C	MOV	MOV R123, #0
007D	MOV	MOV R124, #0
007E	MOV	MOV R125, #0
007F	MOV	MOV R126, #0
0080	MOV	MOV R127, #0
0081	MOV	MOV R128, #0
0082	MOV	MOV R129, #0
0083	MOV	MOV R130, #0
0084	MOV	MOV R131, #0
0085	MOV	MOV R132, #0
0086	MOV	MOV R133, #0
0087	MOV	MOV R134, #0
0088	MOV	MOV R135, #0
0089	MOV	MOV R136, #0
008A	MOV	MOV R137, #0
008B	MOV	MOV R138, #0
008C	MOV	MOV R139, #0
008D	MOV	MOV R140, #0
008E	MOV	MOV R141, #0
008F	MOV	MOV R142, #0
0090	MOV	MOV R143, #0
0091	MOV	MOV R144, #0
0092	MOV	MOV R145, #0
0093	MOV	MOV R146, #0
0094	MOV	MOV R147, #0
0095	MOV	MOV R148, #0
0096	MOV	MOV R149, #0
0097	MOV	MOV R150, #0
0098	MOV	MOV R151, #0
0099	MOV	MOV R152, #0
009A	MOV	MOV R153, #0
009B	MOV	MOV R154, #0
009C	MOV	MOV R155, #0
009D	MOV	MOV R156, #0
009E	MOV	MOV R157, #0
009F	MOV	MOV R158, #0
00A0	MOV	MOV R159, #0
00A1	MOV	MOV R160, #0
00A2	MOV	MOV R161, #0
00A3	MOV	MOV R162, #0
00A4	MOV	MOV R163, #0
00A5	MOV	MOV R164, #0
00A6	MOV	MOV R165, #0
00A7	MOV	MOV R166, #0
00A8	MOV	MOV R167, #0
00A9	MOV	MOV R168, #0
00AA	MOV	MOV R169, #0
00AB	MOV	MOV R170, #0
00AC	MOV	MOV R171, #0
00AD	MOV	MOV R172, #0
00AE	MOV	MOV R173, #0
00AF	MOV	MOV R174, #0
00B0	MOV	MOV R175, #0
00B1	MOV	MOV R176, #0
00B2	MOV	MOV R177, #0
00B3	MOV	MOV R178, #0
00B4	MOV	MOV R179, #0
00B5	MOV	MOV R180, #0
00B6	MOV	MOV R181, #0
00B7	MOV	MOV R182, #0
00B8	MOV	MOV R183, #0
00B9	MOV	MOV R184, #0
00BA	MOV	MOV R185, #0
00BB	MOV	MOV R186, #0
00BC	MOV	MOV R187, #0
00BD	MOV	MOV R188, #0
00BE	MOV	MOV R189, #0
00BF	MOV	MOV R190, #0
00C0	MOV	MOV R191, #0
00C1	MOV	MOV R192, #0
00C2	MOV	MOV R193, #0
00C3	MOV	MOV R194, #0
00C4	MOV	MOV R195, #0
00C5	MOV	MOV R196, #0
00C6	MOV	MOV R197, #0
00C7	MOV	MOV R198, #0
00C8	MOV	MOV R199, #0
00C9	MOV	MOV R200, #0
00CA	MOV	MOV R201, #0
00CB	MOV	MOV R202, #0
00CC	MOV	MOV R203, #0
00CD	MOV	MOV R204, #0
00CE	MOV	MOV R205, #0
00CF	MOV	MOV R206, #0
00D0	MOV	MOV R207, #0
00D1	MOV	MOV R208, #0
00D2	MOV	MOV R209, #0
00D3	MOV	MOV R210, #0
00D4	MOV	MOV R211, #0
00D5	MOV	MOV R212, #0
00D6	MOV	MOV R213, #0
00D7	MOV	MOV R214, #0
00D8	MOV	MOV R215, #0
00D9	MOV	MOV R216, #0
00DA	MOV	MOV R217, #0
00DB	MOV	MOV R218, #0
00DC	MOV	MOV R219, #0
00DD	MOV	MOV R220, #0
00DE	MOV	MOV R221, #0
00DF	MOV	MOV R222, #0
00E0	MOV	MOV R223, #0
00E1	MOV	MOV R224, #0
00E2	MOV	MOV R225, #0
00E3	MOV	MOV R226, #0
00E4	MOV	MOV R227, #0
00E5	MOV	MOV R228, #0
00E6	MOV	MOV R229, #0
00E7	MOV	MOV R230, #0
00E8	MOV	MOV R231, #0
00E9	MOV	MOV R232, #0
00EA	MOV	MOV R233, #0
00EB	MOV	MOV R234, #0
00EC	MOV	MOV R235, #0
00ED	MOV	MOV R236, #0
00EE	MOV	MOV R237, #0
00EF	MOV	MOV R238, #0
00F0	MOV	MOV R239, #0
00F1	MOV	MOV R240, #0
00F2	MOV	MOV R241, #0
00F3	MOV	MOV R242, #0
00F4	MOV	MOV R243, #0
00F5	MOV	MOV R244, #0
00F6	MOV	MOV R245, #0
00F7	MOV	MOV R246, #0
00F8	MOV	MOV R247, #0
00F9	MOV	MOV R248, #0
00FA	MOV	MOV R249, #0
00FB	MOV	MOV R250, #0
00FC	MOV	MOV R251, #0
00FD	MOV	MOV R252, #0
00FE	MOV	MOV R253, #0
00FF	MOV	MOV R254, #0

CHAPTER 4 TECHNICAL DESCRIPTION

4.1 GENERAL

Logic functions that comprise the LPV11 interface are shown in Figure 4-1. Each logic function is briefly described in the following paragraphs. Detailed information can be obtained by referring to drawing CS-M8027 (included in the print set supplied with the option) and the LA180 and LP05 strobe timing diagrams (Figures 4-2 and 4-3, respectively).

4.2 LPV11 INTERFACE FUNCTIONS

4.2.1 General

LPV11 interface functions for use with LP05 or LA180 printers are similar; however, printer strobe signals required by the printer in use are different. By using the specified interface cable for the printer in use, the interface module produces the appropriate printer strobe.

The major part of the LSI-11 bus I/O and interrupt protocol is performed by two special integrated circuits (DC004 and DC003, respectively). These integrated circuit functions are described in the *1977-78 Microcomputer Handbook (Second Edition)*, Appendix F. Refer to drawing CS-M8027 to obtain correct signal names. LPV11 programmed I/O and interrupt transactions are as described in the *Microcomputer Handbook*, Section 1, Chapter 3.

4.2.2 Bus Transceivers and Drivers

Bus transceivers (DEC 8641) receive the LSI-11 bus BDAL<0:7> L signals and distribute the bits on DAL<0:7> H lines. In addition, they transmit LPCS bits or interrupt vector address bits during a DATI bus cycle, or interrupt sequence. Bus drivers (DEC 8881) transmit LPCS bits 8 and 15 during a DATI bus cycle in which the LPCS is addressed.

4.2.3 Device Address Decoding

Device address decoding logic receives DAL<2:7> H, BDAL<8:12> L, and BBS7 signals and compares the address to the device address jumpers (Paragraph 2.2.1); when the LSI-11 bus address bits 2 through 15 equal the jumper-configured address for the LPV11, ENB H goes active. Note that address bits 13, 14, and 15 are not decoded by the LPV11; the LSI-11 processor asserts BBS7 when these bits are all logical 1s, indicating an address is present in bank 7. In addition, address bits <0:2> are decoded for the device register (and byte) in the bus control logic. Bus control logic programmed transfer functions are enabled by the active ENB H signal.

4.2.4 Print Data Transmission

Print data is transmitted to the printer from the LSI-11 bus under program control. The print character buffer functions as the LPDB register. It is an 8-bit register, including the optional Parity/D8 bit. The bus control logic produces WRITE DB H during a DATO or DATOB bus cycle in which the LPDB is addressed. Jumper W8 can be removed to disable program transfer of LPDB bit 07 to the printer. When W8 is removed, P DATA 8 is forced low; if desired, jumper P can be installed to force P DATA 8 high.

Uppercase translation logic gives the user the option to print upper/lowercase data files on an uppercase letters-only printer (LP05-VA, VB, VC, or VD). Software overhead is reduced by performing the lowercase to uppercase translation in hardware, rather than in software. Jumper W7 normally applies unmodified upper/lowercase ASCII characters to the print character buffer. When the lowercase to uppercase letters translation is desired, jumper W7 is removed and jumper T is installed. The result is that ASCII codes 140 through 177 are translated to 100 through 137 (bit 5 = 0), as shown in Table 4-1.

4.2.5 Read Data Select Logic

Read data select logic functions enable the LSI-11 processor to read the LPCS register under program control or the LPV11s interrupt vector during an interrupt transaction. Control signals READ CS H and VECTOR H select the bits. LPCS bits are produced by various LPV11 interface functions as shown on Figure 4-1. Vector address bits are jumper-selected as described in Paragraph 2.2.2.

4.2.6 Ready Flag and LP Strobe Logic

Ready flag (LPCS bit 7) and line printer (LP) strobe logic provides the proper control signal interface to the printer. The LP strobe function is used only for LP05 printers; the LA180 uses the DATA STROBE H signal generated by the bus control logic. Selection of the appropriate strobe source is automatically produced by the LA/LP select logic function. Connecting the proper interface cable for the LA180 grounds the SELECT line, causing the LA/LP select logic to select LA180 (data selector port B) functions. When the LP05 is used, the interface cable does not ground the line and LP05 (data selector port A) functions are selected. The LA180 strobe is a negative-going pulse. The LP05 strobe is a positive-going pulse initiated by the leading edge of P DEMAND H and cleared by the trailing edge of P DEMAND H.

The ready flag is produced by the logic function when the printer is requesting a character (P DEMAND H goes active) and no error is present. In addition to setting the LPCS ready flag, the RQST A signal input to the interrupt logic goes active; if interrupts are enabled (LPCS bit 6 is set), an interrupt request is initiated (BIRQ L goes active). The ready flag is cleared by an active DATA STROBE L signal when writing a new character into the print character buffer.

When an error condition occurs in the printer, the printer asserts P FAULT L. The fault is applied to the error flip-flop logic (via the M FAULT H signal), producing an active ERROR L signal and an active ERROR H signal (LPCS bit 15). The ready flag logic function responds by not producing a ready flag, although P DEMAND H may be active, and by producing an active RQST A H signal. Thus, an error condition will initiate an interrupt request (if LPCS bit 6 is set) and set LPCS bit 15. The error flag is cleared by the processor reading the LPCS register if the ready flag is not set, or when the LPV11s interrupt vector is read.

4.2.7 Error Filter

The error filter is always used (automatically selected) for use with the LA180 printer and jumper selected for optional use with the LP05 printer. This function is produced by a clock pulse generator/counter circuit that requires an active P FAULT L signal for 8 ms before the M FAULT H signal is produced. The minimum time requirement for the fault signal presence prevents false errors due to noise.

4.2.8 BRPLY Delay

Bus control logic generation of BRPLY L signals is delayed 400 ns (approximately) by factory-installed jumper W1. W1 connects C3 to the DC004 RxCx input pin, delaying the BRPLY L signal for proper operation with LA180 printers. When LP05 printers are used, the jumper may be either left installed or removed to reduce the BRPLY delay, as desired.

4.2.9 Initialization

The LSI-11 processor initializes devices on the LSI-11 bus by asserting BINIT L. BINIT L is received by the interrupt logic and distributed as the INIT L signal. INIT L clears the print character buffer, error flip-flop logic, interrupt enable bit (LPCS bit 6), and sets the ready flag.






Figure 4-1 LPV11 Interface Logic Functions






NOTES:

1. TIMING SHOWN IS TYPICAL, AND SHOWN FOR REFERENCE PURPOSES ONLY
2. TIMING SHOWN WITH JUMPER W1 INSTALLED
3. () = INTEGRATED CIRCUIT PINS. REFER TO DWG. CS - M8027
4. TIME IS DETERMINED BY LP05 PRINTER LOGIC.

11-5638

Figure 4-2 LP05 Strobe Timing



- NOTES:
1. JUMPER W1 INSTALLED (REQUIRED) FOR TIMING SHOWN.
 2. TIMING IS TYPICAL, AND SHOWN FOR REFERENCE PURPOSES ONLY.
 3. () = INTEGRATED CIRCUIT PINS. REFER TO DWG. CS M8027.

11-5637

Figure 4-3 LA180 Strobe Timing

Table 4-1 Uppercase-Only Code Translation

ASCII INPUT		ASCII OUTPUT	
Code	Character	Code	Character
140		100	@
141	a	101	A
142	b	102	B
143	c	103	C
144	d	104	D
145	e	105	E
146	f	106	F
147	g	107	G
150	h	110	H
151	i	111	I
152	j	112	J
153	k	113	K
154	l	114	L
155	m	115	M
156	n	116	N
157	o	117	O
160	p	120	P
161	q	121	Q
162	r	122	R
163	s	123	S
164	t	124	T
165	u	125	U
166	v	126	V
167	w	127	W
170	x	130	X
171	y	131	Y
172	z	132	Z
173	{	133	[
174		134	\
175	}	135]
176	^	136	^
177	DEL	137	-

Table 1. Summary of the data

Year	Number of cases	Number of deaths	Number of recoveries
1950	10	0	10
1951	15	0	15
1952	20	0	20
1953	25	0	25
1954	30	0	30
1955	35	0	35
1956	40	0	40
1957	45	0	45
1958	50	0	50
1959	55	0	55
1960	60	0	60
1961	65	0	65
1962	70	0	70
1963	75	0	75
1964	80	0	80
1965	85	0	85
1966	90	0	90
1967	95	0	95
1968	100	0	100
1969	105	0	105
1970	110	0	110
1971	115	0	115
1972	120	0	120
1973	125	0	125
1974	130	0	130
1975	135	0	135
1976	140	0	140
1977	145	0	145
1978	150	0	150
1979	155	0	155
1980	160	0	160
1981	165	0	165
1982	170	0	170
1983	175	0	175
1984	180	0	180
1985	185	0	185
1986	190	0	190
1987	195	0	195
1988	200	0	200
1989	205	0	205
1990	210	0	210
1991	215	0	215
1992	220	0	220
1993	225	0	225
1994	230	0	230
1995	235	0	235
1996	240	0	240
1997	245	0	245
1998	250	0	250
1999	255	0	255
2000	260	0	260
2001	265	0	265
2002	270	0	270
2003	275	0	275
2004	280	0	280
2005	285	0	285
2006	290	0	290
2007	295	0	295
2008	300	0	300
2009	305	0	305
2010	310	0	310
2011	315	0	315
2012	320	0	320
2013	325	0	325
2014	330	0	330
2015	335	0	335
2016	340	0	340
2017	345	0	345
2018	350	0	350
2019	355	0	355
2020	360	0	360
2021	365	0	365
2022	370	0	370
2023	375	0	375
2024	380	0	380
2025	385	0	385
2026	390	0	390
2027	395	0	395
2028	400	0	400
2029	405	0	405
2030	410	0	410
2031	415	0	415
2032	420	0	420
2033	425	0	425
2034	430	0	430
2035	435	0	435
2036	440	0	440
2037	445	0	445
2038	450	0	450
2039	455	0	455
2040	460	0	460
2041	465	0	465
2042	470	0	470
2043	475	0	475
2044	480	0	480
2045	485	0	485
2046	490	0	490
2047	495	0	495
2048	500	0	500
2049	505	0	505
2050	510	0	510
2051	515	0	515
2052	520	0	520
2053	525	0	525
2054	530	0	530
2055	535	0	535
2056	540	0	540
2057	545	0	545
2058	550	0	550
2059	555	0	555
2060	560	0	560
2061	565	0	565
2062	570	0	570
2063	575	0	575
2064	580	0	580
2065	585	0	585
2066	590	0	590
2067	595	0	595
2068	600	0	600
2069	605	0	605
2070	610	0	610
2071	615	0	615
2072	620	0	620
2073	625	0	625
2074	630	0	630
2075	635	0	635
2076	640	0	640
2077	645	0	645
2078	650	0	650
2079	655	0	655
2080	660	0	660
2081	665	0	665
2082	670	0	670
2083	675	0	675
2084	680	0	680
2085	685	0	685
2086	690	0	690
2087	695	0	695
2088	700	0	700
2089	705	0	705
2090	710	0	710
2091	715	0	715
2092	720	0	720
2093	725	0	725
2094	730	0	730
2095	735	0	735
2096	740	0	740
2097	745	0	745
2098	750	0	750
2099	755	0	755
2100	760	0	760

CHAPTER 5 MAINTENANCE

5.1 GENERAL

Maintenance for the LPV11 involves executing a diagnostic program that tests the printer system and, if required, repairing the interface module or the printer. Maintenance procedures for the printers (LP05 or LA180) are covered in the appropriate printer manuals supplied with the option and are not repeated in this manual.

As a general rule, the user should first check that the LPV11 interface module is properly installed as described in Chapter 2 and that printer controls are properly set for operation. If the module appears to be properly installed (jumpers are properly configured, interface cable is properly installed, no unused option locations in the backplane between the LPV11 and the LSI-11 processor module), confirm the operational status of the interface module by executing the diagnostic software supplied with the option. Printer controls are described in printer documents supplied with the LPV11 option.

5.2 DIAGNOSTIC SOFTWARE

The LPV11 option includes diagnostic software in the ZJ178-RB LP11/LP05 Documentation/Paper Tape Kit. Documentation includes diagnostic program listings and detailed operating instructions. The diagnostic program can be input using the binary paper tape included in the kit. Running the program will effectively test the LPV11 printer system, including interface module functions and printer functions.

Minimum hardware requirements for running this diagnostic include the basic LSI-11 system, including 4K read/write memory in Bank 0, a console terminal, and a paper tape reader. Refer to the *Microcomputer Handbook*, Section 1, Paragraph 9.3 for general instructions for using paper tape diagnostics.

5.3 DIGITAL SERVICES

Maintenance services can be performed by the user or by DIGITAL, as desired. DIGITAL's services are described in the *Microcomputer Handbook*, Section 5, Chapter 3.

CONFIDENTIAL
SECRET

1. The first part of the document discusses the general situation of the country and the role of the government in the economy.

2. The second part of the document discusses the specific measures that have been taken to improve the economy and the role of the government in the process.

3. The third part of the document discusses the results of the measures taken and the progress that has been made in the economy.

4. The fourth part of the document discusses the future prospects of the country and the role of the government in the process.

5. The fifth part of the document discusses the conclusions of the study and the recommendations that have been made.

Your comments and suggestions will help us in our continuous effort to improve the quality and usefulness of our publications.

What is your general reaction to this manual? In your judgment is it complete, accurate, well organized, well written, etc.? Is it easy to use? _____

What features are most useful? _____

What faults or errors have you found in the manual? _____

Does this manual satisfy the need you think it was intended to satisfy? _____

Does it satisfy *your* needs? _____ Why? _____

Please send me the current copy of the *Technical Documentation Catalog*, which contains information on the remainder of DIGITAL's technical documentation.

Name _____ Street _____
Title _____ City _____
Company _____ State/Country _____
Department _____ Zip _____

Additional copies of this document are available from:

Digital Equipment Corporation
444 Whitney Street
Northboro, Ma 01532
Attention: Communications Services (NR2/M15)
Customer Services Section

Order No. EK-LPV11-OP-001

11/27/84 10:00 AM
MAYNARD, MASS.
01754

Fold Here

Do Not Tear - Fold Here and Staple

**FIRST CLASS
PERMIT NO. 33
MAYNARD, MASS.**

**BUSINESS REPLY MAIL
NO POSTAGE STAMP NECESSARY IF MAILED IN THE UNITED STATES**

Postage will be paid by:

**Digital Equipment Corporation
Technical Documentation Department
Maynard, Massachusetts 01754**

